


# CASEWOOD STUDIOS

## KALANA NIGHTSTAND RATTAN FT-STB03-02-03-01 / FT-STB03-02-03-02



## ASSEMBLY INSTRUCTIONS

## Introduction

Please read all instructions first.

All you need to assemble your unit is a Phillips screwdriver.

Before you begin, take some time to check all parts against the hardware and parts list on the next pages.

Please place all parts on a soft cloth or carpet to prevent scratching during assembly.













To avoid collapse or injury, DO NOT sit, stand or climb on this unit. DO NOT stack heavy objects on this unit.  
NEVER put a TV on this product.  
NEVER allow children to climb or hang on drawers.

## Care and Maintenance

Clean with a soft damp cloth.

Should a deep scratch or gouge occur, we recommend touch up with a matching paint or stain available in most hardware stores.

# PARTS & HARDWARES

aa = 4 pcs +1 Extra 	bb = 12 pcs +1 Extra 	cc = 16 pcs +1 Extra 	dd = 8 pcs +1 Extra 
ee = 4 pcs +1 Extra 	ff = 8 pcs +1 Extra 	gg = 8 pcs +1 Extra 	hh = 6 pcs 
ii = 16 pcs +1 Extra 	 Tool Required (Not Included)		

- A. TOP ASSEMBLY

B. LEFT ASSEMBLY

C. RIGHT ASSEMBLY

D. TOP RAIL

E. BOTTOM RAIL

F. BACK PANEL
- G. UPPER DRAWER FRONT

H. DRAWER LEFT

I. DRAWER RIGHT

J. DRAWER BACK

K. DRAWER BASE

L. LOWER DRAWER FRONT
- 1X

1X

1X

2X

2X

1X


1X

2X


2X

2X

1X




# 1




# 2

Attach Left and Right Assemblies (B) and (C) to Top and Bottom Rails (D) and (E) using Camlocks (gg) and Dowels (ii).




3



Attach Top Assembly (A) to unit using Wood Screws (aa).


4


Attach Back Panel (F) to unit using Wood Screws (bb).




# 5

- \* Attach Handles (hh) to Upper and Lower Drawer Front (G) and (L) using Wood Screws (ee).
- \* Attach Drawer Left and Right (H) and (I) to Drawer Back (J) using Wood Screws (cc).
- \* Slide Drawer Base (K) into the groove.
- \* Attach Upper and Lower Drawer Front (G) and (L) to Drawer Left and Right (H) and (I) using Wood Screws (cc).
- \* Slide Drawers into position.
- \* Adjust the adjuster that has already been assembled to the legs to stabilize your unit.






# I. IF THE DRAWER DOES NOT ALIGN





Loosen slightly the upper screws.




# II. IF THE DRAWER ALREADY ALIGNS

Insert the drawer into the main body, then adjust the drawer front panel left or right and up or down, until the drawer gaps look proportional.



Pull out drawer slowly. Lock the drawer front panel into position using Wood Screws (dd).



Pull the drawer open slowly and tighten the upper screws. Make sure the front panel does not move and lock the drawer front panel into position using Wood Screws (dd).