


# CASEWOOD STUDIOS

LURIAN QUEEN BED TRADITIONAL  
FT-STB07-02-00-01.A & FT-STB07-02-00-01.B /  
FT-STB07-02-00-02.A & FT-STB07-02-00-02.B



---

ASSEMBLY INSTRUCTIONS

## Introduction

Please read all instructions first.

All you need to assemble your unit is a Phillips screwdriver.

Before you begin, take some time to check all parts against the hardware and parts list on the next pages.












Please place all parts on a soft cloth or carpet to prevent scratching during assembly.

## Care and Maintenance


Clean with a soft damp cloth.

Should a deep scratch or gouge occur, we recommend touch up with a matching paint or stain available in most hardware stores.


# PARTS & HARDWARES

aa = 8 pcs +1 Extra 	Threaded Rod	bb = 8 pcs +1 Extra 	Square Washer	cc = 8 pcs +1 Extra 	Hex Nut
dd = 1 pc 	Hex Wrench	ee = 10 pcs +1 Extra 	Long Bolt	ff = 4 pcs +1 Extra 	Short Bolt
gg = 14 pcs +1 Extra 	Spring Washer	hh = 14 pcs +1 Extra 	Flat Washer	ii = 1 pc 	Allen Wrench
jj = 16 pcs +1 Extra 	Wood Screw	 Tool Required (Not Included)			

- A. CROWN 1X
- B. HEADBOARD 1X
- C. LEFT POST 1X
- D. RIGHT POST 1X
- E. STRETCHER 1X
- F. FOOTBOARD 1X
- G. SIDE RAIL 2X
- H. SLAT 4X
- I. CENTER LEG 8X




# 1




# 2


- \* Attach Crown (A) to unit using Long Bolts (ee), Spring Washers (gg) and Flat Washers (hh).
- \* Tighten Long Bolts (ee) using Allen Wrench (ii).



**3** Attach Threaded Rods (aa) to the Headboard Assembly and Footboard (F). Tighten the rods.




**4**



Attach Side Rails (G) to the Headboard Assembly and Footboard (F) using Square Washers (bb), Hex Nuts (cc). Tighten Nuts Using Hex Wrench (dd).

# 5



Screw in Center Legs (I) to Slats (H).

# 6

- \* Attach Slats (H) to Side Rails (G) using Wood Screws (jj).
- \* Adjust the adjuster that has already been assembled to the legs to stabilize your unit.

