


# CASEWOOD STUDIOS

MIRA STORAGE BENCH SCALLOPED  
FT-STB08-01-03-01 / FT-STB08-01-03-02



---

ASSEMBLY INSTRUCTIONS

## Introduction

Please read all instructions first.

All you need to assemble your unit is a Phillips screwdriver.

Before you begin, take some time to check all parts against the hardware and parts list on the next pages.

Please place all parts on a soft cloth or carpet to prevent scratching during assembly.













To avoid collapse or injury, DO NOT stand on this unit.  
DO NOT stack heavy objects on this unit.  
NEVER put a TV on this product.  
NEVER allow children to climb or hang on unit.

## Care and Maintenance

Clean with a soft damp cloth.

Should a deep scratch or gouge occur, we recommend touch up with a matching paint or stain available in most hardware stores.

# PARTS & HARDWARES

<div>aa = 4 pcs</div> <div>+1 Extra</div> <div>Long Bolt</div> <div></div>	<div>bb = 12 pcs</div> <div>+1 Extra</div> <div>Short Bolt</div> <div></div>	<div>cc = 16 pcs</div> <div>+1 Extra</div> <div>Spring Washer</div> <div></div>
<div>dd = 12 pcs</div> <div>+1 Extra</div> <div>Flat Washer</div> <div></div>	<div>ee = 4 pcs</div> <div>+1 Extra</div> <div>Spacer</div> <div></div>	<div>ff = 1 pc</div> <div>Allen Wrench</div> <div></div>
<div>gg = 8 pcs</div> <div>+1 Extra</div> <div>Wood Screw 1/2"</div> <div></div>	<div>hh = 4 pcs</div> <div>+1 Extra</div> <div>Wood Screw 5/8"</div> <div></div>	<div>ii = 1 pc</div> <div>Hinge</div> <div></div>
<div></div> <div>Tool Required (Not Included)</div>		

A. TOP PANEL1X


B. LEFT ASSEMBLY1X

C. RIGHT ASSEMBLY1X



D. FRONT ASSEMBLY1X

E. BACK ASSEMBLY1X

F. BASE ASSEMBLY1X




1




- \* Attach Front and Back Assemblies (D) and (E) to Left Assembly (B) using Long Bolts (aa), Spring Washers (cc) and Spacers (ee).
- \* Tighten Bolts using Allen Wrench (ff).

2.1.



Slide Base Assembly (F) into the groove.


2.2.




Attach Short Bolts (bb), Spring Washers (cc) and Flat Washers (dd) to unit using Allen Wrench (ff).  
Note: Attach Short Bolts (bb) only halfway this time.

# 3

- \* Attach Right Assembly (C) to unit using Short Bolts (bb), Spring Washers (cc) and Flat Washers (dd).
- \* Tighten all Short Bolts (bb) using Allen Wrench (ff). (Including Short Bolts (bb) in step 2.2.)




# 4





- \* Attach Long Bolts (aa), Spring Washers (cc) and Spacers (ee) to unit.
- \* Tighten Bolts using Allen Wrench (ff).

5



Attach Hinge (ii) to unit using Wood Screws (gg).

6



2 people are recommended for assembly

- \* Attach Top Panel (A) to unit using Wood Screws (gg) and (hh).
- \* Adjust the adjuster that has attached to the legs to stabilize your unit.